







Jienuo IP Camera

PC Software Connection Manual



User:admin password:none








Click the right mouse button and select: Connected Device



Insert the channel into the screen split page



If you have more cameras, please refer to the above method to add it.