# Peace of mind for your loved ones !



## GPS Tracking SOS Pendant



#### Important Notes, please read carefully:

- The company is committed to take technical and management measures to ensure the safety of network information and protect personal information security in accordance with the law according to provisions of laws and regulations of *Decision on strengthening the protection of network information, The NPC Standing Committee decision on safeguarding Internet Security and Regulations on the management of Internet electronic bulletin service.* Please use this product legally. The company is not responsible for any illegal use of this product.
- To ensure safety use of this product, please make sure it is not associated by any unauthorized person and timely modify the login password of App and web platform.
- Due to external factors, all GPS devices have position error, the position information provided by this device is only for your reference.
- This device work to both 2G GSM networks, base on 2G network the device can be used worldwide.
- There may be information delays caused by telecom operators at certain circumstance. Our company doesn't assume any loss of user's personal and property safety caused by the delay.

#### Main Features:

- Real-time tracking
- Historical route playback
- Geo-fence
- SOS alarm & push-button calling
- Talking clock
- Fall alarm
- Vibrate on Ring for incoming call remind
- Two way audio communication
- Mute automatic answering calls for voice monitor
- Low battery & SIM card change reminders

#### Product Specifications:

- 2G GSM: 850/900/1800/1900MHz
- GPRS Standard: Class 12, TCP/IP
- GPS locating time: 60sec with cold boot (open sky) 29sec with warm boot (open sky)

5sec with hot boot (open sky)

- GPS positioning accuracy: 10-15m (open sky)
- WiFi positioning accuracy: 15-100m (wifi area)
- LBS positioning accuracy: 100-1000m
- Working temperature: -18°C ~ +45°C
- Working humidity: 5% ~ 95% RH
- Device host size: 40.5\*43.3\*13.8mm
- Device host net weight:25g
- Battery capacity: 400mA

#### Accessories:

Main host \*1User manual \*1USB charging cable \*1Lanyard \*1

The product consists of hardware device and Apps in Smartphone, only with both of which can user make full use of this GPS tracking SOS pendant.

## Product structure diagram

Hang rope hole



## **Hardware Operating Instructions**

#### Step 1. Preparation before use:

The device requests to choose 2G GSM network-based Micro-SIM card ( same as that for Iphone 4), frequency band refers to product specifications in this manual. Besides, please be sure the GPRS data plan and Caller ID functions have been activated and turn off PIN code function.

#### Step 2. Host power on/off:

Please insert the Micro-SIM card as direction shows on the rubber plug;

Press the Power Button for 3 sec, it powers on when indicator lights on and it rings;

#### In the state of power-on, press the Power Button three times,



Chip side up and narrow edge in Insert the whole card into slot it powers off when indicator lights on and rings.

#### Indicator light instructions:

Details of Network indicator and GPS signal indicator:

Color	Function	Slow	Fast flash	Lights off
		flash		
Blue	GPS	GPS	GPS	GPS
	indicator	Locating	success	sleeping
Red	Network	Network	Network	Network
	indicator	Searching	Ok	sleeping

#### How to answer coming calls

Press any button on the front surface except power one to answer a coming call and press power button to reject a coming call when the device rings and vibrates.

#### How to make outgoing calls

You should setting SOS numbers via the App in your Smartphone first.

**Press button "S"** for 5 sec, the device will send three photos to the App on Smartphone and make calls to all SOS numbers one by one, until someone answers the call. Otherwise, the device will make calls circularly twice.

**Press Dial button "1"**to call SOS number 1 directly; **Talking clock:** Press power button shortly, the device will tell you current time with voice. Please set the device time zone via Smartphone App.

**Fall alarm:** After turning on fall alarm function in App, the device will make alarm sounds when it detects a falling statement. If it is a false alarm, the pendant holder need press the power button to cancel it within 15 sec; If no any operation within 15 sec, the device will alarm according to the way set before.(Please

refer the App setting: Fall alarm) **Special tips:** 

In order to improve the accuracy of fall alerts, user is sugges ted to place the device in a pocket to reduce false alerts caused by device swing when hanging.

### Apps Operation Instructions Apps installation and functions setting

Scan the QR code on manual cover or search for a "any tracking" or "Reachfar" in Apple store or Google play store and download the Apps. (Note: In the process of installing, choose "trust" or "allow" when tips out to ask user to choose whether trust and allow the program to visit phone location otherwise, user can't get a better Apps using effects.)

- 4 After installation, as photo below please choose login with device ID No. which is stuck on the supporter and default password is "123456".
- Make sure the device situation is online, then you can set commands via the Apps.



Real-time tracking: The latest reported position is shown in the map, to renew the location, user can press the refresh button on the top right corner, in about 1 minute, the position will be renewed. > Historical route: There are 3 time periods to check device's historical routes. For data and memory limits, currently the Apps only provides any day's route in 90 days.



Geo-fence: Set or cancel Geo-fence area. In order to avoid false alarm, user is recommended to set radius of fence more than 500m

Settings



- Device Language and timezone > Setting: This module mainly for device hardware settings and operations via App. Please confirm the device is online before making any detailed setting.
- About the device: To show the current device

information User can edit device information and save it by press the top right corner button.

- Change password: To change password of login App, web platform and Wechat location.
- Interval of uploading location data: The default interval time is uploading location data every 10 minutes. guardian can adjust interval time based on real situation. Please pay attention that the shorter interval time you set. the shorter device standby time will be. Usually, we suggest guardian to adjust interval time to 30 sec when searching for device holder and adjust the interval time back to 10 minutes or 1 hour to ensure enough standby time of the device after device holder is found
- Main monitoring number: Only the main monitoring number can receive SIM card changing and low power reminders and send commands to operate the device via SMS
- SOS numbers: Keys "1", "2" and "S" on the device for emergent calls.
- Phone book: Only the numbers saved in phone book can make calls to the device and monitor voice around it remotely, other number's calling will be rejected.
- Answer modes: To set three call answering modes: ■ **Press to answering:** When a call comes, the device
- will ring and vibrate as a phone, user needs to press key"1", "2" or "S" to answer it for two-way communication
- Auto-answer: When a call comes from one of the phone book, the device will ring and vibrate as a phone, after one ring, it answers automatically and user can talk via the device.
- Silent mode: When a call comes from one of the phone book, the device will not ring or vibrate, but answer the call directly, it's a one-way communication for monitor voice around.
- Fall alarm: To turn on/off fall alarm function. When turned on, the device will make alarm sounds if it detects a state of falling down. The device holder can cancel the alarm in 15 sec by pressing any button. If no any

operation within 15 sec, the device will send alarm SMS to the Apps platform and main monitoring number.

- Alarm mode: When fall alarm starts, there are four alarm modes to choose: 1. Alarm only to App: 2. Alarm to both App and make a call to main monitor number; 3. Alarm to App and send SMS to main monitor number: 4. Alarm to App, make a call and send SMS to main monitor number
- Software time zone: If used in China, the device needs no setting for time zone, while used abroad, user can set accordingly in App.
- Device language and time zone: Chinese and English are available for alarm SMS: Time zone: the device has talking clock function, user needs to choose right time zone for local time.
- Remote reboot: If the device works abnormally, user can reboot the device remotely via App.
- **Remote power-off:** Via App to power off the device remotely. Be careful to use it, as it can't be remote powered on after using this function.
- > Alarm list: To show historical list of alarm information.
- **Remind:** When alarm occurs to set whether to receive latest App alarm information or not.
- **Logout:** Logout from App. do not receive any alarms via App.

For locating information via webpage platform, please visit our website: www.gps123.org

## FAO:

**O:** After inserting SIM card, the device can make phone calls, but it says "not enable" both on platform and App.

A: 1. Please confirm the device can send SMS and make calls after inserting SIM card.( Note: locating may fail when SIM card fees owed)

2. APN data is incorrect, you need configure the APN data as below:

1) Bind main number first by sending SMS:

pw.123456.center.phone number# to the device No. For example: pw.123456.center.1370000000#

- 2) The APN configure SMS command is: apn.apndata.user ID.user password.network code#
- 3) For example: The AT&T APN data is *wap.cingular*, The user ID is *wap@cingulargprs.com*. The user password is *cingular1*. The network code is **310410**.(mcc:310.mnc.410) Then the APN configure SMS text is: *ann.wan.cingular*.

#### wap@cingulargprs.com.cingular1.310410#

4) Reboot the pendant tracker after getting a SMS reply. 5) If all ways above don't work, please ask the SIM card operator for right APN data.

PS: APN reference website: http://wiki.apnchanger.org or

#### http://apn-settings.com/

Attention: All commands above use lowercase letters. punctuation marks in English style and end with "#".

## Notes:

- Please read this user manual before use, to ensure right and safe use of the device:
- In power off state, charging will cause auto-power on: Please insert a SIM card before charging.
- Please use this device in a place with strong signal:
- Before use, the device needs to charge with qualified charger for 2-3 hours to get a best use and avoid main host damage. In charging state: Red light on shows in charging, blue light constantly on shows fully charged.
- Standby time is about 2 days within strong network signal.
- This device will reboot when network searching failed or with no SIM card in the state of power-on when charging.
- This device is not waterproof, please use away from water.
- Please leave the device away from fire, extreme heat, freezing cold and other extreme environment.
- This device does not work normally when no battery left or not in a communication network service area.
- The fulfillment of the device's functions relies on GPS

network system, GSM telecom network system, GIS system and computer system, etc. It needs to insert SIM card and have internet access with strong network signal for the device work well. For any loss caused by service interruption for failure of network or other force majeure. our company takes no responsibility.

- To obev the principle of continuous improvement and sustainable development, the company reserves the right to improve any function and parameters described in this user manual without prior notice.
- The information in this manual is provided under products manufacturing situation. The company and the agent shall not be liable for any special, incidental, indirect damages to the extent permitted by law, no matter what the damage cause is.