


4G camera how to connect WIFI?


Q: 4G camera how to connect WIFI?

R: First, you can not configure the 4G camera's WIFI via the phone APP - "WIFI settings".

Need to configure the WIFI through the 4G MIFI page as shown below, if you do not know enter this page, please read the document "**1- You need to know something first in the 4G camera!!**"



mobile phone



PC

Enter "WI-FI Settings" page

4G Mobile Hotspot 192.168.100.1/index.html#home

4G CPE

No Service


Modify Login Password Logout English

System Information

Current Mode: Wireless Broadband Mode [Change](#)

No SIM Card or SIM Card invalid!

Connected Devices	Wi-Fi Settings	SMS	Phonebook	Advanced Settings
-------------------	----------------	-----	-----------	-------------------



Copyright © 2007-2016 All rights reserved

Then enter " Internet Wi-Fi " page, Click the "Add" button to add WIFI.

4G Mobile Hotspot 192.168.100.1/index.html#ap_station

4G CPE

No Service

Modify Login Password Logout English

Wi-Fi Settings

Set up wireless hotspot so that your mobile phone or laptop could access network via it

SSID

Wi-Fi Switch ☒ Enable ☐ Disable

WPS

Internet Wi-Fi

Internet Wi-Fi Switch ☒ Enable ☐ Disable

Preferred Network ☒ Wi-Fi ☐ WWAN

Current Status Wi-Fi connected

WLAN MAC Filter

Wi-Fi Hotspot

Disconnect Delete Edit Add

Option	SSID	Signal	Security Mode
	Bosesh		WPA-PSK/WPA2-PSK

Note:

1. When the WIFI is connected, 4G camera connect Internet via WIFI, if you want the 4G camera connect the Internet via the 4G SIM card, please select "WWAN"

SSID

WPS

Internet Wi-Fi

Advanced Settings

WLAN MAC Filter

Wi-Fi Switch

☒ Enable

☐ Disable

Apply

Internet Wi-Fi

Internet Wi-Fi Switch

☒ Enable

☐ Disable

Preferred Network

☐ Wi-Fi

☒ WWAN

Current Status

Wi-Fi connected

Apply




Wi-Fi Hotspot

Connect

Delete

Edit

Add

Option	SSID	Signal	Security Mode
<input type="radio"/>	Bosesh	  	WPA-PSK/WPA2-PSK